

the e-asy quick start guide



NOCH FRAGEN?
Hotline: +43 (0) 720 / 22 70 60
service@comscoot.com
comscoot.com



AUFBAUVIDEO

01 Auspacken

Heben Sie den E-Scooter vorsichtig aus der Verpackung. Bitte die Verpackung für eventuellen Versand aufbewahren.



02 Zubehörbox

Die Schrauben für die Befestigung des Lenkers befindet sich in der Zubehörbox.




03 Stecker

Stecken Sie den Stecker in Pfeilrichtung zusammen. Achten Sie darauf, dass das Kabel dabei nicht eingeklemmt wird.



04 Verschrauben

1. Abdeckung nach oben schieben.
2. Madenschrauben mit kleinen Inbus festziehen.
3. Inbusschrauben festziehen (schwarzer Griff).



05 Luftdruck

Empfohlener Luftdruck: **3,2 bar / Reifen**
Ein zu geringer Reifendruck kann sich negativ auf die Reichweite auswirken.



06 comscoot APP

QR-Code scannen & App downloaden.
Startkennwort: **649735**
Schalten Sie Bluetooth und GPS ein.



WICHTIGE INFOS



ANLEITUNGEN

Videoanleitung,
Bedienungsanleitung,
Tipps & Tricks



REGISTRIERUNG

Registrieren Sie Ihren
E-Scooter für die volle
Garantie!



ZUFRIEDEN?

Wir freuen uns auf
Ihre Bewertung bei
Google oder eTrustad.



AKKU

Die Akkuleistung liegt inner-
halb der ersten Ladezyklen
noch nicht bei 100%.



WARTUNG

Bitte lassen Sie Ihren E-Scooter
regelmäßig warten. Beachten
Sie die Serviceintervalle! **(1x / Jahr)**

the e-asy quick start guide

ANY QUESTIONS?
 Hotline: +43 (0) 720 / 22 70 60
 service@comscoot.com
 comscoot.com



CONSTRUCTION VIDEO

01

Unpacking

Carefully lift the e-scooter out of the packaging. Please keep the packaging for eventual shipping.



02

Accessory box

The screws for attaching the handlebar can be found in the accessory box.



03

Plug


Plug the connector together in the direction of the arrow. Make sure that the cable is not pinched in the process.



04

Screwing

1. slide the cover upwards. 2. tighten grub screws with small Allen key. 3. tighten the Allen screws (black handle).



05

Air pressure

Recommended air pressure: **3.2 bar / tyre.**
 If the tyre pressure is too low, this can have a negative effect on the range.



06

comscoot APP

Scan QR code & download app.
 Start password: **649753**
 Switch on Bluetooth and GPS.



IMPORTANT INFORMATION



INSTRUCTIONS

Video instructions,
 Operating instructions,
 Tips & Tricks



REGISTRATION

Register your e-scooter for the full warranty!



SATISFIED?

We look forward to your review on Google or eTrusted.



BATTERY

The battery performance is within the first charging cycles not yet at 100%.



MAINTENANCE

Please have your e-scooter serviced regularly. Please note the service intervals! (1x / year)